

WINDSOR



MAINTENANCE

86372300

CLIPPER 12



01) Drain recovery tank and solution tank.



02) Rinse and clean recovery tank.



03) Clean the float shut off.



04) Clean the brush and vacuum shoe.



05) **INSPECT BRUSH:** When the black brush bristles reach the height of the yellow indicator bristles replace the brush.



06) Store brush in the recovery tank with the bearing side up and vent the recovery tank dome to let dry.



07) Soak spray jets in a solution of water and vinegar overnight.

WINDSOR



OPERATION


86372300



01) Install jets and brush.



02) Fill solution tank with extraction rinse or fresh water and replace the lid properly. The notch on the lid should match up with the notch in the tank.



03) Make sure that all three prongs are on the main body of the cord. If one of the prongs is missing, notify your supervisor. Plug into outlet and machine cord and twist to lock.



04) **FOR SPOTTING:** Hook up vacuum line, solution line, and tool if necessary.



05) Adjust handle for push or pull cleaning and operator height.



06) Turn on brush motor.



07) Starting at the highest setting, adjust brush height setting by setting until you hear the brush hit the carpet.

WINDSOR



OPERATION

86372300



08) Turn on the vacuum motor.



09) Choose continuous or intermittent spray. Press buttons on handle to control spray on intermittent mode.



10) Overlap 2-3" on every pass, and on intermittent spray release button and continue pulling for 1 foot before making a new pass.



11) Unplug the cord from the wall when finished.



Bold Innovation. Expert Results.



Bold Innovation. Expert Results.



Bold Innovation. Expert Results.