



MAINTENANCE


86372450



01) Check brushes regularly for wear. When black bristles meet the height of yellow bristles, replace brush.



02) Clean brushes and bearing caps after every use.



03) When bag full light illuminates on the control panel check for clogs and replace the bag as necessary.



04) Replace bag quarterly.



Bold Innovation. Expert Results.



Bold Innovation. Expert Results.




Bold Innovation. Expert Results.



OPERATION

86372450



01) Inspect brushes for wear and replace if necessary. Make sure that the brushes are in the Chevron pattern.



02) WHEN NECESSARY: plug in wand or hose accessory.



03) Pull the quick release to let down the cord.



04) Make sure all three prongs are on the body of the cord.



05) Plug the cord into an outlet.



06) Adjust the height of the handle to a comfortable position.



07) Turn the machine on.