


WINDSOR SABER CUTTER SERIES




MAINTENANCE

86393100



01) Dump & clean
recovery tank



02) Remove squeegee, rinse,
inspect blades for wear/
tear. (if damaged or worn
flip squeegee blade)



03) Empty solution tank



04) Plug in battery



05) Remove dome
(Air out recovery tank)



06) Turn off machine



07) Wipe down outside
of tank

WINDSOR SABER CUTTER SERIES



OPERATION

86393100



01) Inspect squeegee blade for wear or torn blades



02) Inspect Pads (Recommended changing at 1/4" thickness)



03) Fill solution tank



04) Turn on machine



05) Transport to work area (press green handles to move forward) Ready to scrub



06) (Make sure pads are wet before scrub deck is lowered) Increase water. Lower speed. Press green button to engage brush and solution.



07) Lower Scrub Deck

WINDSOR SABER CUTTER SERIES




OPERATION

86393100



08) Lower squeegee arm



09) Turn on vacuum and Press accelerator handles (Green)



10) Adjust speed to desired pace



11) REVERSE: Hold white button and green handle to go in reverse



12) TURNING SCRUBBER
Decrease speed before turn and pull on handle of the side you are turning



13) DOUBLE SCRUB: (Used for heavily soiled areas) Turn off vacuum, make multiple passes and turn on vacuum for last pass



14) DEEP SCRUB
Lock the scrub deck handle into the notch