WINDSOR DOMINATOR WITH HEAT





01) Dump recovery tank into any standard toilet and clean and rinse out recovery tank.



02) Clean wand and accessories





86372340







Bold Innovation. Expert Results.



Bold Innovation, Expert Results.

WINDSOR DOMINATOR WITH HEAT



OPERATION 86372340



01) Fill the solution tank with extraction rinse or fresh water.



02) Plug the cord for heat (right side) and cord for normal operations (left side) into two separate circuit breakers.



03) Connect the vacuum hose and the solution hose to the machine and the accessory.



04) Turn on the pump, vacuum and heat.



05) Adjust the PSI appropriately. COUNTERCLOCKWISE decreases PSI and CLOCKWISE increases



06) Let go of the trigger on the wand two inches before the end of your pass.



07) Unplug both of the cords from the circuit breakers.

WINDSOR DOMINATOR WITH HEAT





08) Be careful not to pull down too hard on the strain reliefs so that the strain reliefs will not be damaged when the cords are wrapped.



09) Wrap the cords for storage starting from the base. Wrapping the cords properly will help prevent cord failure





86372340

WINDSOR



