WINDSOR Admiral 8





01) Drain and rinse recovery tank and solution tank.



02) Clean brush, brush housing, and vacuum shoe.



03) INSPECT BRUSH: When the black brush bristles reach the height of the yellow indicator bristles replace the brush.



04) Store brush in the recovery tank bearing side up.



05) Vent the recovery tank to let dry.



06) Remove spray jets and soak in a solution of hot water and vinegar overnight.



Bold Innovation, Expert Results.

WINDSOR Admiral 8









02) Remove recovery tank and fill solution tank with extraction rinse or fresh water. Replace recovery tank.



03) Make sure that all three prongs are on the main body of the provided cord. If one of the prongs is missing, notify your supervisor. Plug into outlet and control panel and twist to lock.



86372310

04) FOR SPOTTING: hook up vacuum line and solution line if necessary.



05) Adjust the handle to a comfortable position.



06) Turn the brush motor on.



07) Adjust the brush height dial setting by setting until you hear the pitch of the motor change.

WINDSOR

Admiral 8










09) Choose continuous or intermittent spray. Press buttons on handle to control spray on intermittent mode.



10) Overlap 2-3" on every pass and on intermittent spray release button and continue pulling for 1 foot before making a new pass.







WINDSOR WINDSOR